

XRISM Data Processing Pipeline and Software

Michael Loewenstein for the XRISM Science Data Center (SDC)

Matt Holland (PDL), Tahir Yaqoob and Eric Miller, Bob Hill, Trisha Doyle, Patty Hall, Efrain Perez-Solis, and Efrem Braun (alumnus)

This talk



Will cover

- XRISM processing pipeline
- XRISM processing ftools (including reprocessing scripts) and CaIDB
- Some details on the MXS and energy assignment
- XRISM post-processing and data analysis ftools (briefly)
- XRISM / Hitomi differences
- XRISM software status and plans (briefly)

Will *not* cover

- Data (archive) organization, naming conventions, retrieval
- Coordinate system definitions
- Time assignment
- Bright source details (E. Hodges-Kluck)
- Extended source details (F. Mernier)


Will focus on Resolve



- Handles all processing of record from observation scheduling to delivery of pipeline output to data archives.
- Provides proven, standards-based community software tools needed for data processing (calibration, screening), data product extraction, and data product analysis.
- Manages XRISM ground system software and data systems involved in maintaining the XRISM Calibration Database (CaIDB) derived from deliveries from the Xtend, Resolve (and XMA) instrument teams.
- Supports the XRISM Guest Observer Facility (GOF) in user-support activities.

How the Data Flow

X-Ray Imaging and Spectroscopy Mission



- Telemetry from XRISM arrives at ISAS
- PPL converts the telemetry data into FFF
- Data are transferred to the PL virtual machines
- Data are verified and prepared for pipeline processing
- Data are processed
- Data (encrypted) are transferred to the archives


The PL operates in a (mostly) automated manner

- Checks input files for validity
- Determines nominal pointing aberattitude, attconvert, aspect
- Calculates Optical Axis (sky) coordpnt
- Calculates quartz clock temperature trend (backup timing) xatrendtemp (ahrendtemp)
- Collects necessary HK, orbit, and attitude information into "make-filter" (mkf) and "extended HK" (ehk) files (for screening, coordinate assignment) – xamkehk (ahmkehk)
- Calibrates, cleans for each instrument; extracts preview products
- Most tasks make use of the XRISM CalDB (Calibration Database) where all necessary calibration information is stored and indexed.
- The SDC is constructing the pre-flight CaIDB that will be updated based on commissioning and in-flight calibration activities.



XRISM CalDB

(Calibration Database)



What's in the (Current) CalDE

- Hitomi-based data (e.g., XMA) to be updated for first XRISM public release
- Optical axes at center of Resolve 6x6 array and nominal aimpoint for Xtend
- Preliminary deliveries of XRISM-based data (from ground testing) to be updated for XRISM public release
 - MXS parameters CalDB file
 - Temperature vs. Frequency relation for timing
 - Other timing parameters
 - Resolve gain
 - Resolve RMF
 - Xtend bad pixels
 - Resolve & Xtend "teldef" files (detector layout)
- Final pre-flight versions of XRISM-based data (from ground testing)



- Optical axes refined based on ground-based misalignment measurements, but will be further refined using inflight calibration data.
- XMA calibration will have large (~10-20%) systematics above ~8 keV, to be improved post-launch.
- Au optical constants for XMA mirror reflectivity same as Hitomi.
- No Resolve bad pixels.
- Contamination for both Resolve and Xtend set to zero.
- Xtend RMF line-spread function narrower than measured on ground, so users will need to include additional line broadening in models.



Xtend PL Processing (in brief)

X-Ray Imaging and

- Calculate Xtend CCD mode GTI (for expo map) xtdmodegti (sximodegti)
- Assign higher level coordinates coordevt
- Merge inner 3x3 and outer 5x5 pulse heights xtdphas (sxiphas)
- Set initial data quality STATUS flags (for screening) xtdflagpix (sxiflagpix)
- Assign grade and initial energy (PI) xtdpi (sxipi)
- Update grade and PI w/ grade-dependent CTI correction xtdpi (sxipi)
- ID and output flickering pixels among clean events searchflickpix/coordevt
- Update STATUS flags w/ flickering pixel information xtdflagpix (sxiflagpix)

- Filter times
 - HK (nominal instrument status)
 - Telemetry (not saturated)
 - Pointing accuracy, stability
 - Safe angle above Earth, sunlit Earth limb
 - Away from SAA in time and orbit
- Screen events for
 - Grade
 - Data quality (STATUS; not in a "bad" detector area, pixel, row, etc)

(ahtigen + ahscreen)



Resolve Software Concepts

Detector channels (fixed)

| 30 | 32 | 34 | 26 | 24 | 23 |
|----|----|----|----|----|----|
| 29 | 31 | 33 | 25 | 22 | 21 |
| 27 | 28 | 35 | 18 | 20 | 19 |
| 1 | 2 | 0 | 17 | 10 | 9 |
| 3 | 4 | 7 | 15 | 13 | 11 |
| 5 | 6 | 8 | 16 | 14 | 17 |


Resolve Event File Columns

| Column | Description | Range | | |
|-----------|---|---------|--|--|
| ITYPE | Resolution Grade; ITYPE=0: HP, ITYPE=1: MP, ITYPE=2: MS, ITYPE 3: | 0-7 | | |
| | LP, ITYPE 4: LS, ITYPE 5: BL, ITYPE 6: EL, ITYPE 7: Rj | | | |
| PIXEL | Pixel number (pixel 12 is the calibration pixel) | 0-35 | | |
| RISE_TIME | Measured time from baseline to peak for Resolve pulse | | | |
| PI | Linearized Energy Channel | 0-60000 | | |
| STATUS | 16 bit Event Flag (14 in use) | | | |
| | STATUS[1]: in (0) or out (1) of all-pixel GTI file | 0-1 | | |
| | STATUS[2]: in (0) or out (1) of individual-pixel GTI | 0-1 | | |
| | STATUS[3]: coincident with antico events (1) | 0-1 | | |
| | STATUS[4]: coincident with other event within a temporal proximity | 0-1 | | |
| | STATUS[5]: coincident with pixel 12 event | 0-1 | | |
| | STATUS[6]: coincident with pixel 12, and recoil energy test satisfied | 0-1 | | |
| | STATUS[7]: coincident with event in wiring proximity (electrical crosstalk) | | | |
| | – short timescale | 0-1 | | |
| | STATUS[8]: largest PHA in electrical crosstalk group – short timescale | 0-1 | | |
| | STATUS[9]: coincident with MXS, direct mode* | 0-1 | | |
| | STATUS[10]: coincident with MXS afterglow, direct mode* | 0-1 | | |
| | STATUS[11]: coincidence with MXS, indirect mode* | 0-1 | | |
| | STATUS[12]: coincident with MXS afterglow, indirect mode* | 0-1 | | |
| | STATUS[13]: coincident with event in wiring proximity (electrical | 0-1 | | |
| | crosstalk) – long timescale | | | |
| | STATUS[14]: largest PHA in electrical crosstalk group – long timescale | 0-1 | | |
| 0000.0.00 | | • | | |


Resolve Grade (ITYPE)

X-Ray Imaging and Spectroscopy Mission

KRiS




- X-Ray Imaging and Spectroscopy Mission
- The modulated X-ray source (MXS) is the primary source for Resolve energy scale calibration, illuminating each pixel with X-rays generated using LEDs operating with a short pulse period and low duty cycle. The pulsed emission dominated by narrow features of known energy.
- This enables continuous pixel-by-pixel energy gain drift monitoring while avoiding contamination of the astrophysical source.




The Resolve MXS

- X-Ray Imaging and Spectroscopy Mission
- There are direct (LED1/3 on the nominal/redundant side) and indirect (LED2/4 on the nominal/redundant side). The K-shell lines emission lines directly generated by the Cr/Cu anode are primarily used for energy assignment.




- X-Ray Imaging and Spectroscopy Mission
- The XRISM ftools tasks rsImxstime and rsImxsgti calculate "MXS Pulse ON" and "MXS Pulse OFF" time intervals for each LED. The former is used for gain tracking, the latter - extended to include an afterglow tail - to omit times with MXS X-rays from cleaned event files.
- rsImxstime calculates the basic MXS Pulse-ON GTI per LED, and rsImxsgti combines and inverts these in several ways.
- Pulse parameters from HK
 - 1. Pulse length \rightarrow afterglow
 - 2. Pulse spacing
 - 3. Peak intensity (LED Current) \rightarrow offset
- Parameter optimization and operations tradeoffs (bright, but not too bright; frequent, but not too frequent).



Gain and energy assignment


- X-Ray Imaging and Spectroscopy Mission
- Gain curve: Energy as a function of PHA (pulse height amplitude) and operating temperature
- Separately calculated for High, Mid, and Low resolution events for each pixel




XRISM Data Analysis Workshop



- Extract spectra from an onboard calibration source in time intervals over the observation exposure.
- Use knowledge of the intrinsic line energy and shape, and the measured PHA to derive the effective temperature.



Gain Histories (per pixel)




Ri



| Cal method | Cal lines | Pipeline Gain History | Pipeline energy assignment |
|-------------------|---------------------------|------------------------------------|-------------------------------|
| Cal-pix | MnKa, MnKb | Always (MnKa) | If no MXS direct |
| Fe55 | MnKa, MnKb | If FW set to Fe55 (MnKa) | For calibration |
| MXS (direct) | Cuka, Cukb, Crka, Crkb | If MXS direct on (CuKa, CrKa) | Primary method |
| MXS (indirect) | AlKa, AlKb, MgKa, MgKb | If MXS indirect on (AlKa, MgKa) | For calibration |

Methods and lines






- Use MXS if direct mode is enabled, otherwise use cal-pixel.
- Make all possible gain history files


Data Proc. – Resolve Cal.

- Calculate ADR temperature fluctuations (for ADR GTI) rslctsfluct (new)
- Calculate ADR GTI (screening) rsladrgti (new)
- Calculate MXS GTI (screening, energy assignment) rslmxsgti (mxsgti)
- Invert LOST GTI file (expo map) gtiinvert
- Assign antico energy (PI) rslanticolc (sxsanticolc)
- Assign higher level coordinates coordevt



Data Proc. – Resolve Cal.

• Assign pulse clipping flag (screening) – rslplsclip (new)



- Set energy-independent data quality STATUS flags (screening) rslflagpix (sxsflagpix)
- Associate groups of secondary with primary events (energy assignment) rslsecid (sxssecid)
- Compute the energy scale drift correction (energy assignment) rslgain (sxsgain)
- Assign initial energy (PI) rslpha2pi (sxspha2pi)
- Set energy-dependent data quality STATUS flags rslflagpix (sxsflagpix)
- Re-assign groups of secondary events with primary rslsecid (sxssecid)
- Correct secondary event raw pulse heights rslseccor (sxsseccor)
- Assign final energy (PI) rslpha2pi (sxspha2pi) 2023.2.22 XRISM Data Analysis Workshop

Data Proc. – Resolve Clean

- Filter times for
 - HK (nominal instrument status)
 - Telemetry (not saturated)
 - Pointing accuracy, stability
 - Safe angle above Earth, sunlit Earth limb
 - Away from SAA in orbit
 - ADR (not recycling, settling down)
 - MXS (not pulsing, not in afterglow)
- Screen events for
 - Grade (ITYPE<5)
 - Data quality (based on STATUS)
 - Pulse shape (SLOPE_DIFFER, QUICK_DOUBLE)


(ahtigen + ahscreen)




Preview products

Risk X-Ray Imaging and Spectroscopy Mission

 The pipeline constructs a set of standard light curves, images, spectra and response files.



These "preview products" are intended for a *quick* assessment of the data.




- XRISM Users should reprocess data when there has been an update to pipeline software and/or CaIDB since the data was archived; or, if a user wants to apply a non-standard calibration or screening criteria.
- Resolve and/or Xtend data may be reprocessed using the xapipeline script that is part of the standard software library (set the instrument parameter to ALL, Xtend, or Resolve).
- Resolve/Xtend data may also be reprocessed using the rslpipeline/xtdpipeline scripts.
- Users may start/finish the reprocessing at the calibration, screening, or preview product generation stage. The 'pre-calibration' steps of mkf/ehk and ADR GTI and MXS GTI file generation may be skipped (in which case the preexisting files may be used).
- Users essentially have access to all of the parameters for all of the tools that comprise the pipeline – so the full sequence of individual tools rarely if ever need to be run (except by the SDC and instrument teams for verification).
- The pipeline tools include a randomization seed output from multiple, identical runs may not be precisely identical.


Post-pipeline tools - RMF

X-Ray Imaging and Spectroscopy Mission


Ris


| Size | Gaussian core | Exponential tail | Si K alpha emission line* | | Electron loss continuum |
|-------------|------------------|---------------------|------------------------------|--------------|-------------------------|
| Small (s) | \checkmark | × | × | × | × |
| Medium (m) | \checkmark | \checkmark | × | × | × |
| Large (I) | \checkmark | \checkmark | \checkmark | \checkmark | × |
| X-large (x) | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark |





Ri°






Ris

Post-pipeline tools - RMF

X-Ray Imaging and Spectroscopy Mission


Ri



- An ARF describes the *effective* area of an X-ray telescope as a function of energy

 essentially the *geometric* area multiplied by the efficiency at which photons may
 be detected.
- The xaarfgen task creates an ancillary response function (ARF) file for the XRISM Resolve and Xtend instruments using raytracing simulation.
- Inputs include
 - Exposure map Where the telescope is looking and for how long (pointing histogram, effective exposure per pixel)
 - Location of the source in the sky
 - Spatial distribution and extent of the source (point-like or extended)
 - Extraction region (match to spectrum)
 - Physical model of the telescope and any obstructions in the optical path (geometry, material composition and their optical properties)
 - Detector efficiency
 - Filter transmission curves
- The xaarfgen task invokes the raytracing task xrtraytrace, using the above inputs, to run a monte-carlo simulation of the photon paths through the X-ray telescope.

Post-pipeline tools - ARF



Ris

- The non-X-ray background (NXB) is an irreducible background that is not due to X-ray photons (mostly high-energy charged particles) collected by the optics and focused on the detector.
- Xtend and Resolve will accumulate a database that will be accessible online and downloadable of NXB events during Earth occultations when XRISM is pointed toward the dark limb of the Earth.
- Xtend and Resolve NXB generators (xtdnxbgen, rslnxbgen) extract events from the NXB database, matching the spacecraft and instrument conditions and settings.
- The Resolve NXB is expected to be low in cleaned event lists (~0.0003 cts/sec/pixel for Hitomi SXS), but will have an additional MXS component TBD.





- Some notable updates (in addition to the new tasks mentioned) are as follows:
 - Software / CaIDB (not including CaIDB content, bug fixes)
 - MET origin from 2014-01-01 to 2019-01-01
 - Resolve MXS pulse delay, pulse offset, afterglow treatment
 - Unified Resolve energy scale
 - New Resolve pixel dependencies (QE, non-core LSF)
 - New Resolve grade dependencies (trigger-to-arrival time correction)
 - Xtend RMF accounts for response to incoming photon energy of peak output channel
 - Additional flexibility in Xtend event flagging
 - Updated algorithm (e.g., CTI correction) treatment in Xtend energy assignment
 - Resolve RMF accounts for Si Ka emission fluorescent line
 - Resolve RMF energy dependence of ELC, split RMF with separate ELC extensions
 - Additional complexity (accuracy, tuning capabilities) in modeling the optics (external objects such as the TS, inner foils, FW, GV)

XRISM Data Anal

- All Hitomi tasks are maintained as part of a dual architecture where common code may be shared.
- Most XRISM tasks have diverged from their Hitomi cognates (improvements, bug fixes), but changes are mostly "under the hood".
- Some Hitmomi tasks are deprecated (obsolete or redundant)
 - sxsperseus, sxsregext, sxsextend
- Comprehensive Functional and Lightweight Field Test for automated regression-checks of validated unit-tests.
 - (LFT) delivered to end users as part of ftool release
- Documentation
 - Improved help files
 - Doxygen bridges the code and help files
 - Easy access and documentation of XRISM software
 - Full access to task code and associated codes/libraries
 - Easy to navigate code components
 - Structure follows the directory structure of HEASoft.
- Final internal pre-flight release: Spring 2023 (XRISM V1.0 release candidate)
- First HEASoft release: After commissioning (XRISM; commissioning updates plus bug fixes)





Hitomi -XRISM

EXTRA SLIDES



EXTRA SLIDES

XRISM Data Analysis Workshop

The SOT = SDC + SOC

The XRISM pipeline (PL) is a collection of daemons running on a set of virtual machines hosted at the NASA/GSFC. Each daemon is responsible for a different aspect of data transfer, processing, and validation (next slide).

The PL converts first FITS files (FFFs) – basic event and housekeeping telemetry in FITS format with time-tagging constructed by the pre-pipeline (PPL) located at JAXA/ISAS, into calibrated and screened FITS files suitable for scientific investigation, and into trend products used to monitor instrument health and performance.

2023.2.22

DARTS ODB **ARK/RPS** XOSS SOC Operations PPL data sources and processes SDC **SDC** Archive PL management (B5) HEASARC




JP


US


Data Processing/Distribution in Detail



















| | | MXSTYPE | | |
|-------------------------|------------------------|------------------|--------------------|------------------|
| | | NOM (nominal) | RED (redundant) | OFF |
| MXSLED13 (direct) | Bright, medium, or dim | LED1 is ON | LED3 is ON | N/A |
| | OFF | LED1 is OFF | LED3 is OFF | All LEDs are OFF |
| MXSLED24 (in-direct) | Bright, medium, or dim | LED2 is ON | LED4 is ON | N/A |
| | OFF | LED2 is OFF | LED4 is OFF | All LEDs are OFF |








- Photons are redistributed to other, mostly lower detected energy (PI).
- RMF components for SXS/Resolve:
 - Gaussian main peak -
 - Exponential shoulder/tail
 - Escape peaks
 - Electron loss continuum (ELC)






- Photons are redistributed to other, mostly lower detected energy (PI).
- RMF components for SXS/Resolve:
 - Gaussian main peak ·
 - Exponential shoulder/tail-
 - Escape peaks
 - Electron loss continuum (ELC)












- Photons are redistributed to other, mostly lower detected energy (PI).
- RMF components for SXS/Resolve:
 - Gaussian main peak
 - Exponential shoulder/tail
 - Escape peaks
 - Electron loss continuum ' (ELC)












X-Ray Imaging and Spectroscopy Mission

Work is in progress on enhancements and additions to the raytracing and ARF generation suite of software.

- 1. Enhancements have been made to the core raytracing program xrtraytrace to accommodate geometrical changes to the inner foil structure, and to implement more accurate thermal shield modeling.
- 2. A new tool, xmasim, is being developed that is a driver for xrtraytrace, adding many capabilities.
- 3. Enhancements planned for the ARF generator tool that introduce options for distributed computation of the effective area, with statistical errors, and on-the-fly raytracing of the Resolve filters and gate valve.
- 4. PSF library planned for Resolve, enabling spectroscopy that accounts for crosscontamination of spatial regions due to the PSF spatial redistribution.
- 5. Will include the effects of dust scattering on the PSF and effective area.
- 6. Prototype work has started in order to run xrtraytrace on AWS Batch



X-Ray Imaging and

Spectroscopy Mission